




2 years of warranty

Bolivia: 800-100156
Colombia: 01800-5181617
Costa Rica: 800-4357237
Salvador: 800-6773
Honduras: 800-25616099
Mexico: 001800-5148611
Panama: 011-00800-2268611
Peru: 0800-54674
Donican Republic: 1888-7514876
Venezuela: 0800-1627485



BKU-606X/1006X

User Manual



Advanced Power Protection

A Full line of products designed for the modern family with advanced features and characteristics needed for todays modern devices.

SAFETY INSTRUCTION



CAUTION! To prevent the risk of fire or electric shock, install in a temperature and humidity controlled indoor area free of conductive contaminants. (See the specifications for the acceptable temperature and humidity range.)

CAUTION! To reduce the risk of overheating the UPS, do not cover the UPS's cooling vents and avoid exposing the unit to direct sunlight or installing the unit near heat emitting appliances such as space heaters or furnaces.

CAUTION! Do not attach non-computer-related items, such as medical equipment, life-support equipment, microwave ovens, or vacuum cleaners to the UPS.

CAUTION! Do not plug the UPS input into its own output.

CAUTION! Do not allow liquids or any foreign object to enter the UPS. Do not place beverages or any other liquid-containing vessels on or near the unit.

CAUTION! In the event of an emergency, press the OFF button and disconnect the power cord from the AC power supply to properly disable the UPS.

CAUTION! Do not attach a power strip or surge suppressor to the UPS.

CAUTION! If the UPS has a metal chassis, for safety purpose, the UPS must be grounded during installation in order to reduce leakage current below 3.5mA.

Attention! Hazardous through electric shock. Also with disconnection of this unit from the mains, hazardous voltage still may be accessible through supply from the battery. The battery supply should be therefore disconnected from the plus and minus pole by removing the quick connectors of the battery cables when maintenance or service work inside the UPS is necessary.

CAUTION! Servicing of batteries should be performed or supervised by personnel knowledgeable of batteries and the required precautions. Keep unauthorized personnel away from batteries.

CAUTION! When replacing the batteries, use the same number and type of batteries.

CAUTION! Internal battery voltage is 12VDC. Sealed, lead-acid, 6-cell battery.

CAUTION! Do not dispose of batteries in a fire. The battery may explode. Do not open or mutilate the battery or batteries. Released electrolyte is harmful to the skin and eyes.


CAUTION! Unplug the UPS prior to cleaning and do not use liquid or spray detergent.

CAUTION! A battery can present a risk of electric shock and high short circuit current. The following precaution should be observed before replacing batteries:

- 1) Remove watches, rings, or other metal objects.
- 2) Use tools with insulated handles.
- 3) Wear rubber gloves and boots.
- 4) Do not lay tools or metal parts on top of batteries.
- 5) Disconnect charging source prior to connecting or disconnecting battery terminals.

This product is an intelligent line interactive UPS (Uninterruptible Power Supply) which is designed to protect your personal computer or sensitive electronic equipment from all forms of power interference, including complete power failure. It is equipped with many features that allow any attached equipment to operate longer and more reliably.

1. Product Overview



1. Power switch.
2. UPS status indicator:
AC mode: green lighting
BAT mode: green flashing
3. Output receptacle.
4. Surge-protected receptacles.
5. AC input.
6. Circuit breaker.

2. Installation and Operation

NOTE: Before installation, please inspect the unit. Be sure that nothing inside the package is damaged.

1) Placement & Storage Conditions.

Install the UPS in a protected area that is free of excessive dust and has adequate air flow. Please place the UPS at least 20 cm away from other electronic equipment to avoid interference. Do NOT operate the UPS where the temperature exceeds 0-40° C and the humidity is over 0-90% RH.

2) Connect to Utility and Charge

Plug in the AC input cord to the wall outlet. For the best results, we suggest charging the battery for at least 6 hours before initial use. The unit charges its battery when connected to AC power supply.

3) Connect the Load.

Plug in the loads to output receptacles on the rear panel of the UPS. Simply turn on the power switch of the UPS unit, and devices connected to the UPS will be protected by the UPS unit.



Do not attach a power strip or surge suppressor to the UPS.

NEVER connect a laser printer or scanner to the UPS unit, because in-rush current generated by motor's devices may cause damage to the unit.



4) Turn On/Off the Unit.

Encienda el UPS pulsando el interruptor de encendido. Apague la unidad UPS pulsando el interruptor de encendido.

3. Trouble Shooting

Use the table below to solve minor problems.

Problem	Possible Cause	Solutions
No words displayed on the front panel.	Low battery.	Charge the UPS for at least 6 hours.
	Battery fault.	Replace the battery with the same type of battery.
	The UPS is not turned on.	Press the power switch again to turn on the UPS.
Alarm sounds continuously.	Please check fault code table for the details.	Please check fault code table for the details.
	The UPS is overloaded.	Remove some critical load.
When power fails, back-up time is reduced.	Battery voltage is too low.	Charge the UPS at least 6 hours.
	Battery defect. May be due to high temperature operation environment, or improper operation of battery.	Replace the battery with the same type of battery.
The mains supply is normal, but the UPS is operating in battery mode.	Power cord is loose.	Reconnect the power cord properly.

If any abnormal situations occur that are not listed above, please call for service immediately.

Specifications

Model	BKU-606X	BKU-1006X
CAPACITY	650VA/360W	1000VA/600W

Input

Voltage	110/120Vac
Frequency	60 Hz
Voltage Range	81~145Vac

Output

Voltage	110/120Vac
AC Voltage Regulation	+/- 10%
Frequency Range	60HZ ± 1Hz
Waveform	Simulated Sinewave
Transfer Time	2-6ms, 10 ms. Max.
Outlets Nema 5-15R	4 with backup / 2 surge protected

Battery

Battery Type & Number	12V/7AH x 1	12V/7AH x 2
Typical Recharge Time	4-6 hours recover to 90% capacity	

Indicators

LCD indicator	AC mode \ BAT mode \ overload \ AVR mode \ fault \ input voltage output voltage \ output fre \ load percent \ battery capacity
LED Indicator	AC mode indicator and BAT mode indicator

Protection

Full Protection	Overload, discharge, and overcharge protection
-----------------	--

Alarm

Battery Mode	Sounding every 10 seconds
Low Battery	Sounding every second
Overload	Sounding every 0.5 second
Battery Replacement Alarm	Sounding every 2 seconds
Fault	Continuously sounding

Physical

Dimension, D X W X H (mm)	279 x 101 x 142	320 x 130 x 182
Net Weight (kgs)	4.2	8.2

Environment

Humidity	0-90 % RH @ 0- 40°C (non-condensing)
Noise Level	Less than 45dB

Management

Optional USB / RS-232 port	Supports Windows® 2000/2003 / XP / Vista / 2008 / 7,10 Linux, Unix and MAC
Certifications	CIDEI, ISO9001, ISO14001, NOM, TÜV

Warranty

CHICAGO DIGITAL POWER INC. warrants this product for a period of one year (with possible extension up to 2 years) on all parts and labor against defects and workmanship from the date of delivery to the consumer.

I. To enforce this guarantee greater requirement cannot be required that the presentation of this policy with the product (except Mexico) in the place of purchase or service center CHICAGO DIGITAL POWER INC. against defects in manufacture and operation, imperfections of materials, parts, components and labor. For information on service centers in your country, so you should contact (other countries write servicio@cdpups.com):

Bolivia: 800-100156
Colombia: 01800-5181617
Costa Rica: 800-4357237

Salvador: 800-6773
Honduras: 800-25616099
Mexico: 001800-5148611
Venezuela: 0800-1627485

Panama: 011-00800-2268611
Peru: 0800-54674
Donican Republic: 1888-7514876

II. CHICAGO DIGITAL POWER INC. will repair the product and in the event that you consider not to be beyond repair; to change the team, as well as defective parts and components thereof without charge to the owner during the warranty period, and the cost Transportation Product reasonably incurred arising from compliance.

III. The repair time will not exceed thirty days from the date of receipt of the product at any of the sites where it can be guaranteed and where may also purchase parts and parts.

IV. Should this warranty policy is lost, the consumer can use your provider to issue a duplicate of the warranty policy on presentation of the sales slip or invoice.

This warranty does not apply in the following cases:

- When the product has been used in other than normal conditions.
- The product has not been operated in accordance with the instruction manual that accompanies it.
- The product has been altered or repaired by persons not authorized by the domestic manufacturer, importer or marketer respective responsible.
- Does not apply to normal wear or damage from accidents. Lack of physical earth and reversed polarity will void warranty.



(Please fill and deliver this data. Other way you won't be granted to access to the warranty)
 (Warranty won't be given if the unit isn't with this format at the time of giving back to purchase point)

Name: _____	Purchase point seal
Address: _____	
Phone: _____	
E-mail: _____	
Name and address purchase site : _____	Delivery date
Purchase point e-mail: _____	
Product: Regulator <input type="checkbox"/> UPS <input type="checkbox"/> No-Break <input type="checkbox"/> Inversor <input type="checkbox"/>	
Model: _____	